

## Vt-737sp Compressor Fast Attack Modification

1. Opto-cell board (assy 5600-7374) behind VU meter.
2. Replace C5 capacitor (2.2uf 63V standard) with new capacitor 1uf 63V (fast attack)

**C4 Capacitor = Release = M 10u 63V (standard)**



**C5 Capacitor = Attack = M 1u0 63V (fast)**



**M 10u 63V**

**M 1u0 63V**

Make sure to read the capacitor correctly.